



Assembly 1

No.	Code	Description	Quantity
1	A9218-001	1250 Upright	1
2	Z0122-001	432x400 Base	1
3	CM420-001	100x130x75 Tray	1
4	LS007-M06-20	M6x20 Flat head screw	3
5	LS004-M06-20	M6x20 Brazier head screw	4
6	LSM03-M06	M6 Flange nut	7

Assembly 2

Hand Sanitising Station Installation Guide

rapidline
FURNITURE FOR TODAY