

# **ADJUSTING MECHANISM**

- \*Seat height adjustment: Turn lever A
- \*Seat & back tilt with multi-lock: Turn lever B upwards to make back tilt

Lean back and turn lever B downwards to lock back in multi position

\*Tension control: Turn knob to make chair suit your weight.

# **ERGONOMIC INSTRUCTION**

- \*For good blood circulation, adjust the seat height to make your feet rest flat on the floor.
- \*Adjust the angle of the backrest to give firm support while sitting upright.
- \*Adjust the lumbar height to give support to the lumbar region of your back.
- \*Your forearms should be close to horizontal by pressing button of the armrest to adjust the height of armrest.

### **MAINTENANCE**

- \*Protect the chair from direct sunlight.
- \*Check and tighten all the bolts periodically.

## **FABRIC CARE**

- \*Vacuum regularly and gently.
- \*Wipe clean with damp cloth.
- \*Use leather cleaner where leather is applicable.
- \*Test on concealed before proceeding.

#### **CASTOR**

\*Hard-tyred castors are unsuitable for use on hard floors or firm chair mats in which case soft-tyred castors should be used. Soft-tyred castors are distinguishable by the tyres being a different color to the body of the castor.

# **WARNING**

- \*Do not use this chair unless all bolts/knob are tightened and this chair is assembled firmly and properly.
- \*This chair is for one person to sit on. Do not stand on the chair.
- \*Do not touch mechanism except lever handle/knob when people is sitting in.
- \*Only trained personnel replace or repair cylinder.
- \*Failure to follow these warnings could result in serious injury.

