










ASSEMBLY INSTRUCTIONS

CCW186-C

CCW1875-C















pin	6×35
	1
	14PCS
CAM	
	2
	14PCS
Cam Cover	
	3
	14PCS
	



ASSEMBLY INSTRUCTIONS

CCW186-L

CCW1875-L



ASSEMBLY INSTRUCTIONS

CCW186-R

CCW1875-R

