








Assembly Instructions


MODEL NO: C3FC



A


<p>Cushion $\varnothing 42 \times 25H$</p>  <p>1</p> <p>4PCS</p>	<p>$\varnothing 6 \times 40$</p>  <p>4</p> <p>2PCS</p>
<p>Wood Screw 3.5×13</p>  <p>2</p> <p>16PCS</p>	<p>Wood Screw 4×40</p>  <p>5</p> <p>2PCS</p>
<p>$73 \times 23 \times 15$</p>  <p>3</p> <p>2PCS</p>	<p>Wood Screw 4×16</p>  <p>6</p> <p>2PCS</p>

STEP1



IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children




Assembly Instructions

MODEL NO: C3FC


The warning sticker provided within this hardware kit **MUST** be attached to the piece furniture in a place that is 100% visible when the item is empty.

STEP2

Make a mark with a pencil




STEP3




Drill holes at the marks with an electric drill


STEP4



STEP5



STEP1



⚠ WARNING



Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture




This furniture type is at high risk of toppling over

Ask staff for more information or visit <https://www.productsafety.gov.au>


IMPORTANT NOTE:







- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children




Assembly Instructions

MODEL NO: C4FC




<p>Cushion $\varnothing 42 \times 25H$</p>  <p>1</p> <p>4PCS</p>	<p>$\varnothing 6 \times 40$</p>  <p>4</p> <p>2PCS</p>
<p>Wood Screw 3.5×13</p>  <p>2</p> <p>16PCS</p>	<p>Wood Screw 4×40</p>  <p>5</p> <p>2PCS</p>
<p>$73 \times 23 \times 15$</p>  <p>3</p> <p>2PCS</p>	<p>Wood Screw 4×16</p>  <p>6</p> <p>2PCS</p>

STEP1



IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children




Assembly Instructions

MODEL NO: C4FC


The warning sticker provided within this hardware kit **MUST** be attached to the piece furniture in a place that is 100% visible when the item is empty.

STEP2

Make a mark with a pencil




STEP3




Drill holes at the marks with an electric drill


STEP4



STEP5



STEP6



⚠ WARNING



Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture



This furniture type is at high risk of toppling over

Ask staff for more information or visit <https://www.productsafety.gov.au>

IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children

