



Assembly Instructions

MODEL NO: ISFD96




Pin 6×35 20PCS	Shelf Pin 4PCS	Lock 1PCS	 ø6×40 2PCS
Cam 20PCS	Hinge (full-overlay) 4PCS	Wood Screw 4×20 4PCS	Wood Screw 4×40 2PCS
Cam Cover 20PCS	Wood Screw 4×16 26PCS	ADJ. Feet ø42×35H 4PCS	
Wood Screw 3.5×13 18PCS	Lock Catcher 1PCS	73×23×15 2PCS	


STEP1



STEP2




STEP3



First insert the pin(part#1), then place the cam(part#2), and finally tighten/lock off after they have been put into the melamine


STEP4



First insert the pin(part#1), then place the cam(part#2), and finally tighten/lock off after they have been put into the melamine.

IMPORTANT NOTE:


- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children




Assembly Instructions

MODEL NO: ISFD96



STEP5



STEP6



STEP7



IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children




Assembly Instructions

MODEL NO: ISFD96


The warning sticker provided within this hardware kit **MUST** be attached to the piece furniture in a place that is 100% visible when the item is empty.

STEP8

Make a mark with a pencil




STEP9




Drill holes at the marks with an electric drill

STEP10




STEP11

WALL



STEP12

WALL



⚠ WARNING



Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture




This furniture type is at high risk of toppling over

Ask staff for more information or visit <https://www.productsafety.gov.au>


IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children




Assembly Instructions

MODEL NO: ISFD1245/ISFD1545




Pin 6×35 1 28PCS	Shelf Pin 5 8PCS	Lock 9 2PCS	73×23×15 13 2PCS
Cam 2 28PCS	Hinge (full-overlay) 6 4PCS	Wood Screw 4×20 10 8PCS	ø6×40 14 2PCS
Cam Cover 3 28PCS	Wood Screw 4×16 7 38PCS	ADJ. Feet ø42×35H 11 6PCS	Wood Screw 4×40 15 2PCS
Wood Screw 3.5×13 4 28PCS	Lock Catcher 8 2PCS	Hinge(half-overlay) 12 2PCS	


STEP1




STEP2



STEP3




STEP4



IMPORTANT NOTE:


- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children




Assembly Instructions

MODEL NO: ISFD1245/ISFD1545


STEP5





STEP6



STEP7




STEP8



IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children




Assembly Instructions


MODEL NO: ISFD1245/ISFD1545

The warning sticker provided within this hardware kit **MUST** be attached to the piece furniture in a place that is 100% visible when the item is empty.


STEP9




STEP10




STEP11



STEP12



STEP13



WARNING



Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture




This furniture type is at high risk of toppling over

Ask staff for more information or visit <https://www.productsafety.gov.au>


IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children




Assembly Instructions

MODEL NO: ISFD1845




Pin 6×35 1 33PCS	Shelf Pin 5 8PCS	Lock 9 2PCS	73×23×15 13 2PCS
Cam 2 33PCS	Hinge (full-overlay) 6 4PCS	Wood Screw 4×20 10 8PCS	ø6×40 14 2PCS
Cam Cover 3 33PCS	Wood Screw 4×16 7 50PCS	ADJ. Feet ø42×35H 11 6PCS	Wood Screw 4×40 15 2PCS
Wood Screw 3.5×13 4 28PCS	Lock Catcher 8 2PCS	Hinge(half-overlay) 12 4PCS	

STEP1




STEP2




STEP3

First insert the pin(part#1), then place the cam(part#2), and finally tighten/lock off after they have been put into the melamine.




STEP4



First insert the pin(part#1), then place the cam(part#2), and finally tighten/lock off after they have been put into the melamine.

IMPORTANT NOTE:


- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children




Assembly Instructions

MODEL NO: ISFD1845


STEP5




STEP6



STEP7




STEP8



IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children




Assembly Instructions

MODEL NO: ISFD1845


The warning sticker provided within this hardware kit **MUST** be attached to the piece furniture in a place that is 100% visible when the item is empty.

STEP9

Make a mark with a pencil




STEP10




Drill holes at the marks with an electric drill


STEP11



STEP12



STEP13



⚠ WARNING



Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture



This furniture type is at high risk of toppling over

Ask staff for more information or visit <https://www.productsafety.gov.au>

IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children

