
Assembly Instructions
Wave-Shape Aluminium Picnic Table






Before assembly please check you have all parts listed below.


PLEASE NOTE: We've tried to make this table as easy to assemble as possible.

In the unlikely event you have problems putting it together or missing pieces, please contact us.


PARTS LIST

A table top  x 1	B bench seat  x 2	C legs  x 4	D (m8x20 screw)  x 32	F  x 32
			E  x 32	G allen key  x 1

Step 1: Attach table top



Step 2: Attach bench seats





Please recycle these instructions