



# Assembly Instructions


MODEL NO: SPC12 SPC18 SPC10 SPC9




Pin 6×35 1 21PCS	Cam 2 21PCS	Cam Cover 3 21PCS	Shelf Pin 4 16PCS
Handle AMH08-128 5 2PCS	Handle Screw 4×25 6 4PCS	ADJ. Feet ø42×25H 7 6PCS	Wood Screw 3.5×13 8 26PCS
Lock 9 1PCS	73×23×15 10 2PCS	ø6×40 11 2PCS	Wood Screw 4×40 12 2PCS
Wood Screw 4×16 13 2PCS			



## STEP1




## STEP2




First insert the pin(part#1), then place the cam(part#2), and finally tighten/lock off after they have been put into the melamine.

### IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children




## STEP3




First insert the pin(part#1), then place the cam(part#2), and finally tighten/lock off after they have been put into the melamine.


## STEP4




## STEP5




## STEP6



## STEP7




## STEP8



### IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children




# Assembly Instructions

MODEL NO: SPC12 SPC11 SPC10 SPC9


The warning sticker provided within this hardware kit **MUST** be attached to the piece furniture in a place that is 100% visible when the item is empty.

## STEP9

Make a mark with a pencil




## STEP10




Drill holes at the marks with an electric drill

## STEP11




## STEP12

WALL



## STEP13



## ⚠ WARNING



### Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture



This furniture type is at high risk of toppling over

Ask staff for more information or visit <https://www.productsafety.gov.au>

### IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children

