


Assembly Instructions


MODEL NO:ML-3 WRML-305/3 WRML-400/3 WRML-380/3




A

Pin 6×35 1 27PCS	Hinge (full-overlay) 4 6PCS	Lock 7 3PCS	Wood Screw 4×20 10 12PCS	Wood Screw 4×40 13 2PCS
Cam 2 27PCS	Wood Screw 4×16 5 36PCS	Lock Catcher 8 3PCS	73×23×15 11 2PCS	Wood Screw 4×16 14 2PCS
Cam Cover 3 27PCS	ADJ. Feet 6 4PCS	Wood Screw 3.5×13 9 6PCS	ø6×40 12 2PCS	


STEP1




STEP2



STEP3




First insert the pin(part#1), then place the cam(part#2), and finally tighten/lock off after they have been put into the melamine.





1: LOOSEN (B) SCREWS
2: ADJUST DOOR VERTICAL
3: TIGHTEN (B) SCREWS AGAIN

STEP4




First insert the pin(part#1), then place the cam(part#2), and finally tighten/lock off after they have been put into the melamine.

STEP5




1: LOOSEN SCREW (A)
2: ADJUST DOOR IN DEPTH
3: TIGHTEN SCREW (A) AGAIN




1: LOOSEN SCREW (A)
2: ADJUST DOOR SIDWAYS
WITH SCREW (C)
3: TIGHTEN SCREW (A) AGAIN

STEP6



IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children




Assembly Instructions


MODEL NO:ML-3 WRML-305/3 WRML-400/3
WRML-380/3

The warning sticker provided within this hardware kit **MUST** be attached to the piece furniture in a place that is 100% visible when the item is empty.

STEP7 Make a mark with a pencil




STEP8




Drill holes at the marks with an electric drill


STEP9



STEP10



STEP11



⚠ WARNING



Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture



This furniture type is at high risk of toppling over

Ask staff for more information or visit <https://www.productsafety.gov.au>

IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children

